


POWDER-COATED CUP COVERS

- ▶ Rotate cup covers instead of cups.
- ▶ Keeps holes free of top dressing material and debris.
- ▶ Lid will sit flush to green when installed properly.
- ▶ 4 ¼" (10.8 cm) cover is powder-coated steel. 6" (15.2 cm) and 8" (20.3 cm) covers are powder-coated aluminum.

Lip indented on bottom to fit inside cup. 6" and 8" only.



Note: Use Cup Setter to ensure proper cup depth of 1" (2.5 cm).


| 1" (2.5 cm) high | 4 ¼" (10.8 cm) diameter | 6" (15.2 cm) diameter | 8" (20.3 cm) diameter |
|--------------------------|-------------------------|-----------------------|-----------------------|
| 4 ¼" (10.8 cm) Cup Cover | 18500 | – | – |
| 6" (15.2 cm) Cup Cover | – | 18650 | – |
| 8" (20.3 cm) Cup Cover | – | – | 18750 |

CUP HOOK

- ▶ Simple and easy way to remove any style cup.

11 ½" (29 cm) long

Cup Hook 33200



RECYCLED RUBBER CUP COVER

- ▶ For low-play seasons or during top dressing.
- ▶ Economical, recycled cover "fills" top of hole; doesn't damage mowers.
- ▶ Sits on top of the cup, flush with surface of the green.

1" (2.5 cm) high 4 ¾" (10.6 cm) diameter

Rubber Cup Cover 18550



Note: Use Cup Setter to ensure proper cup depth of 1" (2.5 cm).

CUP SETTER

- ▶ Set it, step on it and lift it out.
- ▶ Sets cup to USGA-specs – 1" (2.5 cm) – below surface of the green.
- ▶ Flattens and smoothes crowning caused by hole cutters.
- ▶ Minimizes damage to the rims of aluminum cups.

Cup Setter 30100

RECYCLED HOLE REDUCER

- ▶ Ideal for practice greens.
- ▶ Helps players fine-tune putting skills.
- ▶ Sits flush on top of the cup to reduce size of cup opening by 1" (2.5 cm).

1" (2.5 cm) high 4 ¾" (10.6 cm) diameter

Rubber Hole Reducer 18000



Note: Use Cup Setter to ensure proper cup depth of 1" (2.5 cm).



"If you want to accomplish anything in life, you have to enjoy what you're doing. That's why I work here. Everyone here shares a passion for this game and the superintendents who nurture it."

Lind
Sales Manager