



ECONOMY FOAM GUN APPLICATOR

Economy Foam Gun Applicator
Item #54003



Instructions

STEP 1

- Before putting a can of foam on the gun, press the trigger down to release any air trapped in the barrel.

STEP 2

- Shake foam can and thread the can into the gun.

NOTE: do not overtighten.

STEP 3

- Squeeze trigger to allow foam to fill the barrel.

STEP 4

- Adjust the flow by tightening or loosening the flow-adjustment screw found on the back of the gun.

STEP 5

- For best results, mist the area to be foamed with water first.

STEP 6

- When finished, tighten the flow-adjustment screw fully until trigger is locked.

General Maintenance

- Nozzle tip can be cleaned using a wire brush or similar material. DO NOT scrape on rough surface such as concrete or rocks.
- If the gun barrel is clogged, use a can of Foam Gun Cleaner (Item #22011) to flush out the barrel.
- If the ball valve, located in the gun where the can is attached, becomes stuck, use a thin object such as a pencil, to press down on the ball to release.



WARNING: Always keep a can of foam on the gun. Failure to do so will cause foam to harden in the barrel and clog the gun.

For more information about our company or products, please visit our website at aquascapeinc.com or call us at US (866) 877-6637 or CAN (866) 766-3426