



Better footing for better swings.

No matter what kind of shoes a golfer is wearing, grass removal is critical to ensuring proper footing. Putting shoe cleaners on every hole lets golfers know you're interested in improving playability.

Because Golfers Notice.

SPIKE BRUSHES

- Crimped nylon bristles are dense to prevent matting, yet soft enough for both spikeless and plastic spiked shoes.
- Base is made of black anodized cast aluminum, so there's no paint to chip.

SUPER TIP

Give your golfers better footing by adding a spike brush on any ball washer pipe.



Floor Mount Combination Spike and Shoe Cleaner
549-11



Single Pipe Mount Spike Brush
Mounts easily to ball washer pipe.
552-11



Double Pipe Mount Spike Brush
Mounts easily to ball washer pipe.
553-11



Spike Brush Parts
Base Brush
554-11 Fits all models



Side Brush
548 Fits 549, 512 & 513 models



Pipe Mount Back Clamp
552-3 With hardware