

## Replacement Parts

| ITEM | DESCRIPTION                                  | CATALOG #      |
|------|--|----------------|
| 1    | Shroud with Lens                             | LFXW70XX*      |
| 2    | Screws, Optics                               | See LED Chart  |
| 3    | LED Board                                    | See LED Chart  |
| 4    | Screws                                       | †              |
| 5    | Gasket, Qty: 6                               | 250031370000SP |
| 6    | Body and Driver                              | †              |
| 7    | Screws                                       | †              |
| 8    | Set Screw, ¼"-20 x ⅜", ⅛" Allen key, Qty: 12 | 250032740000SP |
| 9    | Assembly, Knuckle                            | KAM050EXAXX*   |
| 10   | Spike  | 250015840000   |
| 11   | Mini J-Box                                   | MJB050XX*      |

XX\* = Finish code

YY\* = Beam angle (SP, FL, WF)

†This part is not serviceable. Contact Customer Support or a local distributor to order a complete product.

## LED Replacement

| DESCRIPTION                          | CATALOG #    |
|--------------------------------------|--------------|
| LED Board, H1, Warm 2,700K           | KITH1W*      |
| LED Board, H1, Soft 3,000K           | KITH1S*      |
| LED Board, Zone/Dim, H1, Warm 2,700K | KITZDH1W*    |
| LED Board, Zone/Dim, H1, Soft 3,000K | KITZDH1S*    |
| LED Board, ZDC, 6 LED                | KITZDC6*     |
| Optics Kit for H1 Board              | KITOPXW70H1  |
| Optics Kit for ZDC Board             | KITOPXW70ZDC |

\* = Zoning, Zone/Dim, and ZDC boards are not interchangeable on the same fixture

