

Key to Parts




D5377 Hose Barb | 1/2" Male Thread X 3/8" 90°
D5381 Hose Barb | 1/4" Male Thread X 3/8"
D5384 Decal | Quality Made In The USA
D5387 Decal | Serial Number | SL-80
D5388 Decal | Serial Number | SL-80SS
D5901 Hopper Frame | SL-80
D5904 Wheel 13" X 5"
D5906 Frame Stand | SL-80
D5908 Handle | SL-80
D5915 Axle
D5917 Handle Grip
D5919 Cotter Pin | 2" Stainless
D5923 Wheel Bushing
D5943 Bolt | 1/4"-20 X 2-1/4" Hex
D5994 Grease Fitting
D6024 Shaft Collar
D6131 Bolt | 1/4"-20 X 1/2" Serr. Flange
D6132 Bolt | 1/4"-20 X 3/4" Serr. Flange
D6172 Bolt | #10-32 X 5/8" Serr. Flange
D6822 Cable Tie | Push Mount
D6854 Bolt | 1/4"-20 X 1" Serr. Flange
D6988 Hose | 3/8"
F50000 Battery Bracket | SL-80
F50001 Wand Bracket | SL-80
F50002 Battery
F50003 Hose Guide | SL-80
F50004 Pump Enclosure | SL-80
F50005 Pump
F50006 Pump Enclosure Cover | SL-80
F50007 Inside Nozzle Body Bracket | SL-80
F50008 Coil Hose
F50009 Tank

F50011 Panel Mount Valve
F50012 Outside Nozzle Body Bracket
F50013 Hose Barb | 1/4" Male Thread X 3/8" 90°
F50014 Nozzle | Push Sprayer
F50015 Nozzle Body
F50016 Harness | Pump
F50019 Battery Bracket | SL-80SS
F50020 Wand Bracket | SL-80SS
F50021 Hose Guide | SL-80SS
F50022 Pump Enclosure | SL-80SS
F50023 Pump Enclosure Cover | SL-80SS
F50024 Inside Nozzle Body Bracket | SL-80SS
F50025 Outside Nozzle Body Bracket | SL-80SS
F50078 Battery Charger
F50079 Decal | On / Off - SL-80
F50080 Decal | Spray / Wand - SL-80
F50106 Harness | Switch
F50107 Switch
F50108 Tank Strainer
F50109 Rubber Grommet
F50111 Reducing Bushing | 3/8" X 1/4"
F50112 Bolt | 5/16"-18 X 1-1/4" Hex
F50145 Hose Clamp | 3/8"
F50651 Pipe Plug | 1/2"
F50775 Owner's Manual
T15016 Nut | 1/4"-20 Nylox
T15018 Nut | 5/16"-18 Nylox
T20307 Spot Spray Wand
T20317 Decal | Caution - Wear Safety Goggles
T30151 Hopper Frame | SL-80SS
T30152 Frame Stand | SL-80SS
T30153 Handle | SL-80SS

Handle Assembly Parts Breakdown




Model # SL-80



Handle Assembly Parts Breakdown



Model # SL-80



BOM ID	Description	Qty
1	D5908	1
2	D5917	2
3	D6132	1
4	D6406	1

BOM ID	Description	Qty
5	F50001	1
6	F50008	1
7	F50016	1
8	F50106	1


BOM ID	Description	Qty
9	F50107	1
10	F50112	2
11	T15016	1
12	T15018	2

BOM ID	Description	Qty
13	T20307	1

Handle Assembly Parts Breakdown




Model # SL-80SS



Handle Assembly Parts Breakdown



Model # SL-80SS




BOM ID	Description	Qty
1	D5917	2
3	D6406	1
4	F50008	1
5	F50016	1

BOM ID	Description	Qty
6	F50020	1
7	F50106	1
8	F50107	1
9	F50112	2

BOM ID	Description	Qty
10	T15016	1
11	T15018	2
12	T20307	1
13	T30153	1

Tank Assembly Parts Breakdown


Model # SL-80



Tank Assembly Parts Breakdown



Model # SL-80



ID #	Part #	Qty
1	D5377	1
2	D5381	1
3	D5901	1
4	D5904	2
5	D5906	1
6	D5915	1
7	D5919	2


ID #	Part #	Qty
8	D5923	4
9	D5943	4
10	D5994	2
11	D6024	2
12	D6854	3
13	F50009	1
14	F50011	1

ID #	Part #	Qty
15	F50013	1
16	F50108	1
17	F50487	1
18	F50651	1
19	T15016	4

Tank Assembly Parts Breakdown




Model # SL-80SS



Tank Assembly Parts Breakdown



Model # SL-80SS



ID #	Part #	Qty
1	D5377	1
2	D5381	1
3	D5904	2
4	D5915	1
5	D5919	2

ID #	Part #	Qty
6	D5923	4
7	D5943	4
8	D5994	2
9	D6024	2
10	D6854	3


ID #	Part #	Qty
11	F50009	1
12	F50011	1
13	F50013	1
14	F50108	1
15	F50487	1

ID #	Part #	Qty
16	F50651	1
17	T15016	4
18	T30151	1
19	T30152	1

Pump Assembly Parts Breakdown




Model # SL-80



Pump Assembly Parts Breakdown



Model # SL-80



ID #	Part #	Qty
1	D5377	1
2	D6131	11
3	D6132	2
4	D6172	4
5	D6988-16.5	1
6	D6988-30	1
7	D6988-40	1
8	F50000	1


ID #	Part #	Qty
9	F50002	1
10	F50003	1
11	F50004	1
12	F50005	1
13	F50006	1
14	F50007	1
15	F50012	1
16	F50014	1

ID #	Part #	Qty
17	F50015	1
18	F50109	3
19	F50145	6
20	F50651	1
21	T15016	2

Pump Assembly Parts Breakdown




Model # SL-80SS



Pump Assembly Parts Breakdown



Model # SL-80SS



ID #	Part #	Qty
1	D5377	1
2	D6131	11
3	D6132	2
4	D6172	1
5	D6988-16.5	1
6	D6988-30	1
7	D6988-40	1

ID #	Part #	Qty
8	F50002	1
9	F50005	1
10	F50014	1
11	F50015	1
12	F50019	1
13	F50021	1
14	F50022	1

ID #	Part #	Qty
15	F50023	1
16	F50024	1
17	F50025	1
18	F50109	3
19	F50145	6
20	F50651	1
21	T15016	2