



- NOTES:**
1. SEE AEC PREMIER COCONUTSM SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.
 2. STAPLE PATTERNS ARE DEPENDENT ON SITE CONDITIONS. SEE AEC PREMIER COCONUTSM STAPLE PATTERN GUIDE FOR DETAILS.
 3. E-STAPLES[®] MAY BE USED IN PLACE OF WIRE STAPLES.




CHANNEL INSTALLATION METHOD "A"
NO SCALE




CHANNEL INSTALLATION METHOD "B"
NO SCALE


CHANNEL DETAIL
NO SCALE




CHANNEL TERMINATION PLAN
NO SCALE




CHANNEL TERMINATION
NO SCALE




SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE




CHANNEL BLANKET END
NO SCALE




STEP 1



STEP 2



STEP 3



STEP 4

CHANNEL TRENCHING METHOD "B"
NO SCALE

CHANNEL TRENCHING METHOD "A"
NO SCALE

NO. REV.	DATE	REVISIONS	PROJECT	MANAGER	DESIGNED BY	APPROVED BY	SHEET DESCRIPTION		SCALE	DATE 5/1/03	DRAWN BY: KK	SHEET NO.
							AMERICAN EXCELSIOR COMPANY ARLINGTON, TEXAS					
							AEC PREMIER COCONUT SM CHANNEL APPLICATION DETAIL		NONE			13

