

Count on it.

Parts Catalog

INFINITY Series Golf Sprinkler Body, 1" and 1.5"

Model No. INFINITY Series



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwiseDEG: degrees

DPA: Dual Point Adjustment **ECM:** electronic control module

EXT: external
FH: flat head
GA: gauge
HD: heavy-duty
HF: hex flange
HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread

forming

HJ: hex jam

HLH: hex lag head **HOC:** height-of-cut

HSBH: hex socket button head HSFH: hex socket flat head HSH: hex socket head HWH: hex washer head

HWHTF: hex washer head thread

forming

HYD: hydraulic **LH:** left hand

LP: Liquefied Petroleum Gas **LPG:** Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head **PPH:** phillips pan head

PPHTF: phillips pan head thread

forming

PRH: phillips round head **PTH:** phillips truss head

PTO: power-take-off

RH: right hand ROPS: roll-over protection system

RRB: rear roller brush
SFH: slotted fillister head
SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head **SQH:** square head


SRH: slotted round head

STD: standard
TAP: self tapping
TTH: torx truss head

Contents

INFINITY Series 1 Inch Golf Sprinkler Body	 . 4
INFINITY Series 1.5 Inch Golf Sprinkler Body	 . 6

INFINITY Series 1 Inch Golf Sprinkler Body




INFINITY Series 1 Inch Golf Sprinkler Body (continued)

				-		_	•
Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	118-1840	1	Marker, Blank	7	102-2709	1	Solenoid Assy., 24Vdc,
1	118-3029	1	Marker, Laser Etched				Latching (Red W/ White
2	118-1813	1	Cover				Stripe And Black Wires)
3	4102001	6	Screw, Tap, 10-16 X 1.25	7	118-0841	1	Gdc Module, 1-Station, Golf
4	118-1826	1	Pilot Valve, Spike-Guard				Body With Solenoid
			Solenoid	8	118-3031	1	Body, W/ Comp, 1" Acme
4	118-1982	1	Pilot Valve W/O Solenoid	9	364-1164	1	Plug, Cable Access
4	118-1983	1	Pilot Valve W/ Nickel Plated	10	89-4702	1	Snap Ring, Valve
			Spike-Guard Solenoid	11	102-0623	1	Cylinder Assy., El & No/Com
4	118-1984	1	Pilot Valve W/ Dc Latching	12	102-6411	1	Spring, Valve, El/No, Silver
			Solenoid	13	35-9646	1	Filter Assy., Metering, El, Nc
4	118-1985	1	Pilot Valve W/ 600/700	14	89-1054	1	Piston Assy., El & Nc
			Solenoid				(Include Item 13)
5	118-1815	1	Retainer, Check Valve	15	102-0784	1	Rock Screen, 1"
6	118-1827	1	Check Flow Assy., Vih		118-3651	1	Wire Splice Kit (Includes 2
_			Communication				Gel Caps And 2 Wire Nuts)
7	118-0248	1	Solenoid, 600/700 Series				■•
_			(Red & Black Wires)		995-80	1	Nut Driver, 1/2 (For Check
7	102-3443	1	Solenoid-Low Wattage,				Flow Assembly) ■ ●
			W/Surge Protection (Black				
_	400 0444		Wires)				
7	102-3444	1	Solenoid-Low Wattage,				
			W/Surge Protection, Nickel				
			Plated (Red Wires)				

● SERVICE ITEMS ■ Not illustrated

380-0072A

INFINITY Series 1.5 Inch Golf Sprinkler Body



INFINITY Series 1.5 Inch Golf Sprinkler Body (continued)

Dof	Dort Number	04.	Description	Dof	Dort Number	04.	Description
Ref.	Part Number	Gty.	Description	Ref.	Part Number	Qty.	Description
1	118-1840	1	Marker, Blank	7	102-2709	1	Solenoid Assy., 24Vdc,
1	118-3029	1	Marker, Laser Etched				Latching (Red W/ White
2	118-1813	1	Cover				Stripe And Black Wires)
3	4102001	6	Screw, Tap, 10-16 X 1.25	7	118-0841	1	Gdc Module, 1-Station, Golf
4	118-1826	1	Pilot Valve, Spike-Guard				Body With Solenoid
			Solenoid	8	118-3030	1	Body, W/ Comp, 1.5" Acme
4	118-1982	1	Pilot Valve W/O Solenoid	9	364-1164	1	Plug, Cable Access
4	118-1983	1	Pilot Valve W/ Nickel Plated	10	3-3304	1	Snap Ring, Valve
			Spike-Guard Solenoid	11	102-0626	1	Cylinder Assy., El And
4	118-1984	1	Pilot Valve W/ Dc Latching				No/Com
			Solenoid	12	102-6411	1	Spring, Valve, El/No, Silver
4	118-1985	1	Pilot Valve W/ 600/700	13	35-9645	1	Filter Assy., Metering, El &
			Solenoid				Nc
5	118-1815	1	Retainer, Check Valve	14	102-5101	1	Piston Assy., El
6	118-1827	1	Check Flow Assy., Vih	15	102-6065	1	Rock Screen, 1.5"
			Communication		118-3651	1	Wire Splice Kit (Includes 2
7	118-0248	1	Solenoid, 600/700 Series				Gel Caps And 2 Wire Nuts)
			(Red & Black Wires)				■●
7	102-3443	1	Solenoid-Low Wattage,		995-80	1	Nut Driver, 1/2 (For Check
			W/Surge Protection (Black				Flow Assembly) ■ ●
			Wires) `				3,
7	102-3444	1	Solenoid-Low Wattage,				
			W/Surge Protection, Nickel				
			Plated (Red Wires)				

● SERVICE ITEMS ■ Not illustrated

380-0072A

